

Fig.10 離合器

項次	部品番號	英文名稱	中文名稱	用量	備註	代碼	工時
1	5ML-E6111-01	GEAR, PRIMARY DRIVE	主驅動齒輪	1			
2	93306-27210	BEARING	軸承	1			
3	93102-22800	OIL SEAL	油封	1			
4	4CW-E6611-00	CLUTCH HOUSING COMP.	離合器殼整體	1			
5	90179-14427	NUT	螺帽	1			
6	90201-144M8	WASHER, PLATE	平墊圈	1			
7	5ML-E7620-02	PRIMARY SLIDING SHEAVE COMP.	主滑動槽輪整體	1			
8	93101-21170	OIL SEAL	油封	2			
9	5ML-E7632-00	WEIGHT	滾珠	6			
10	5ML-E7623-00	CAM	凸輪	1			
11	5ML-E7653-00	SLIDER	滑件	3			
12	90387-16801	COLLAR	軸環	1			
13	5ML-E5657-00	CLUTCH, ONEWAY	單向離合器	1			
14	90208-12050	WASHER, CONICAL SPRING	錐形彈簧墊圈	1			
15	90201-16802	WASHER, PLATE	平墊圈	1			
16	5ML-17641-00	V-BELT	皮帶	1			
17	4HP-E7611-00	SHEAVE, PRIMARY FIXED	主固定槽輪	1			
18	95307-12700	NUT	六角螺帽	1			
19	4CW-E7660-01	SECONDARY FIXED SHEAVE COMP.	副固定槽輪	1			